

SUPER EMULSION

PRODUCT BENEFITS



EXTRA
COVERAGE



ANTI-FUNGAL



SUPREME
QUALITY



LEAD FREE



ENVIRONMENT
FRIENDLY



PRODUCT FEATURES

WASHABILITY



✓ BEST IN CLASS

HIGH
MEDIUM
LOW

COLOURS AVAILABLE

50+

Factory Made Direct Shades



TYPICAL SURFACES

- New surfaces.
- Previously painted surfaces.
- Powdery dusty surfaces.
(With cracks and other surface defects)

AVAILABLE PACKS



0.91 Litre 3.64 Litre 14.56 Litre

FINISH



SMOOTH SHINY NORMAL LOW

✓ SMOOTH

SPREADING RATE



2 COAT

On previously painted surfaces to get the one coat hiding up to 100sqft per liter/ per coat



3 COATS

On new surfaces up to 100 sq.ft per liter by two coats

PREPARATION REQUIRED



Surface must be clean, dry and free from efflorescent salts. After priming with Master Wall Primer, fill and smooth the surface with Master Wall Putty.



Remove all defective or poorly adhering material by rubbing down using a suitable abrasive paper and dust off. Spot prime and fill surface as described.



Make good minor defects. For large holes and cracks use sand and cement mixture. Allow to dry. Prime surface and then fill any surface imperfection with the filler described above. Allow to dry. Scuff surface using abrasive paper and dust off.

TECHNICAL INFORMATION

- Coverage
100-120 sq.ft liter / coat
- Application
Brush / Roller / Spray Gun
- Thinner
Clean Water
- Drying Time
2-3 hours between coats
- No of Coats
2-3
- Cleaning
Clean all equipment with Water
- Thinning
By Roller / Brush 50-75%
By Spray 25%

SAFETY & ENVIRONMENTAL NOTES

Keep away from ignition sources because it is flammable.
You must wear eye protection while applying paint. Always keep container air tight close. It must be kept out of children's reach. In case of contact with eyes, wash with brimful cup of water and immediately approach doctor. Always manage container to keep it in upright position. Protect it from extreme temperatures. Please do not empty into drain and water sources. Use of mask is advisable while rubbing down and same is true when applying by spray never breath vapor / spray. In case ventilation is insufficient the use of proper respiratory equipment is advised.